ANZO USA

5150 Eucalyptus Avenue Unit A
Chino, Ca. 91710
888.360.3696
www.anzousa.com

STOP

Completely read all the instructions before installation
Improper installation will void warranty!

Step 1

Tools needed:
10mm Socket
Phillip Screw Driver
Plastic Pin Remover
Wire Splice Connectors

Step 2

Remove the plastic pin located at the top of the OEM headlight

Step 3

Remove the grille shroud and expos the two 10mm bolts on the side of the OEM headlight

Step 4

Remove the three 10mm bolts located on the top and side of the OEM headlight

Step 5

Remove the OEM headlight by removing the headlight, signal and side marker bulb housing

Step 6

Remove all light bulbs out of its harness

Step 7

Remove the Anzo headlights out of its box

Step 10

Step 8

Twist the two red wires and two black wires together from Anzo headlight

Step 11

Step 9

Splice the two twisted red wires from the Anzo headlight to the brown wire from the harness

Step 12

Splice the two twisted black wires from the Anzo headlight to the black wire from the harness

Connect the headlight, signal, and side marker harness into its power source sockets

Instsll the Anzo headlights by reversing steps 2 to 4

Step 13

Test all functions before operating the vehicle

se