



Installation Instructions

15356B

2009-20* RAM 1500 TRUCKS WITH FACTORY DUAL TAILPIPES

*will carry on through 2020 for Ram 1500 Classic models only.

-Black Ceramic Coated-

WORK SAFELY! For maximum safety, perform this installation on a clean, level surface and with the engine turned off. Place blocks or wedges in front of and behind both rear wheels to prevent movement in either direction.

CAUTION: To avoid any possibility of bodily injury or damage to vehicle, do not attempt installation until you are confident that the vehicle is safely secured and will not move.



1) Locate the clamped connection just behind each of the factory exhaust tips, spray the clamp bolt with a penetrating lubricant and allow to soak. Loosen the bolts and remove the factory tips from the vehicle.

2) The factory clamps will be re-used with the new Flowmaster tips. There is a small weld securing the clamp to the tip, wiggle the clamp back and forth to break the weld and remove the clamp from the tip.



3) Place a factory clamp onto one of the new Flowmaster tips and put up into position behind the resonator on the right tailpipe. Tighten the clamp enough to hold the tip in place and adjust to the desired position. Tighten the clamp securely. Repeat this step on the left side of the vehicle.



PACKING LIST

<u>Qty</u>	<u>Description</u>	<u>Part#</u>
2	Black Ceramic Coated	ST497