



## WEATHERBEATER™ FLOOR LINERS

PT #2071

### CARE AND USE INSTRUCTIONS

---

Thank you for selecting a WeatherBeater™ Trunk Liner from Husky Liners. Your cargo liner is custom molded to fit your Jeep Wrangler 2-Door model. Upon removal from the box your liner will not completely unroll and lay flat. This is normal and only temporary. Just place the liner on the floor of your vehicle with a weight in each corner (a book works well). After about 15 minutes, your liner will remain flat. In colder climates the “flattening” process will take longer; moving the liner to a heated area will accelerate the process.

Your liner is manufactured using an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Use of Armor All®, Son-of-a-Gun® or similar items is discouraged as these products make the liner slick.

### INSTALLATION INSTRUCTIONS FOR YOUR 2-DOOR JEEP WRANGLER JL CARGO LINER



YOUR WRANGLER CARGO LINER IS DESIGNED TO ACCOMMODATE THE FACTORY CARGO TIE-DOWN HOOKS. TO ACCESS THE HOOKS WITH YOUR LINER IN PLACE SIMPLY TRIM AWAY THE MATERIAL FROM ANY/ALL OF THE TIE-DOWN LOCATIONS (SHOWN ABOVE DARKENED). TO AID IN TRIMMING THE AREAS ARE RECESSED IN THE PART. A UTILITY KNIFE WORKS WELL FOR TRIMMING.

TO MOUNT YOUR 2<sup>ND</sup> ROW SEAT ON TOP OF YOUR LINER, PLEASE SEE THE INSTRUCTIONS ON THE BACK OF THIS PAGE.

View the Husky Liner Lifetime Warranty at [www.huskyliners.com/lifetime-warranty](http://www.huskyliners.com/lifetime-warranty)



## WEATHERBEATER™ FLOOR LINERS

PT #2071

### INSTALLING YOUR 2<sup>ND</sup> ROW SEAT ON TOP OF YOUR HUSKY CARGO LINER

FIRST, REMOVE YOUR 2<sup>ND</sup> ROW SEAT. THEN, TRIM YOUR LINER. THE LINER INCLUDES FOUR TRIM AREAS FROM WHICH THE MATERIAL WILL HAVE TO BE REMOVED BEFORE YOU CAN INSTALL YOUR 2<sup>ND</sup> ROW SEAT ON TOP OF THE LINER. USING A UTILITY KNIFE OR SIMILIAR TOOL, TRIM AWAY THE MATERIAL FROM INSIDE THE PROTECTIVE RIBS AS SHOWN BELOW. THE INSIDE EDGE OF THE PERIMETER RIB IS YOUR TRIM GUIDE.

