

# SPEC-D *Tuning*

(OEM HALOGEN ONLY)

## 2007-UP MINI COOPER PROJECTOR HEADLIGHTS INSTALLATION INSTRUCTIONS

\*If you experience any difficulties that the instructions did not cover, Please seek assistance at local automotive shop.

\*Please wear protection before you work on your vehicle.

\*An assistant is useful when removing the front bumper from your vehicle.

\*Please be cautious when working with the bumper or any parts belonging to the vehicles' body prevent scratching.

\*Do not make direct contact with the halogen bulb or the wire assembly until the unit has cooled down after use.



### TOOLS AND SUPPLIES REQUIRED

¼" Drive Ratchet

10mm Socket

6" Extension

If your Headlight is Halo type, you also need:

If your Headlight is Halo type, you also need:

Wire Stripper

Wire Crimper

4 Blue Quick Splice Wire Connectors

4 Blue Male Quick Wire Connectors

4 Blue Female Quick Wire Connectors

2 Red Wires (8 inch)

2 Black Wires (8 inch)

### Product Part Numbers:

2LHP-MINI06JM-TM

2LHP-MINI06-TM

2LHP-MINI06G-TM





## 2007-UP MINI COOPER PROJECTOR HEADLIGHTS INSTALLATION INSTRUCTIONS

- \*If you experience any difficulties that the instructions did not cover, Please seek assistance at local automotive shop.
- \*Please wear protection before you work on your vehicle.
- \*An assistant is useful when removing the front bumper from your vehicle.
- \*Please be cautious when working with the bumper or any parts belonging to the vehicles' body prevent scratching.
- \*Do not make direct contact with the halogen bulb or the wire assembly until the unit has cooled down after use.



1. (2) 10mm bolts location



2. Remove the (2) 10mm bolts



3. Remove the (2) 10mm bolts



4. (2) 10mm bolts location





5. Remove the (2) 10mm bolts



6. Remove the (2) 10mm bolts



7. Disconnect the headlight harness



8. Remove the headlight



9. Connect the headlight harness to the new headlight  
Please see the "Halo and L.E.D installation instructions"  
If your headlights don't have HALO or L.E.D. you can skip it



10. Place the new headlight in the stock location





11. Tighten the (2) 10mm bolts



12. Tighten the (2) 10mm bolts



13. Tighten the (2) 10mm bolts



14. Tighten the (2) 10mm bolts



15. Please repeat the steps in order from 1 to 14 for the opposite side



16. The installation is now complete