

# 35103

**50-inch Straight LED Light Bar  
Upper Windshield Mounting Brackets  
09-15 Dodge Ram 1500, 10-15 Ram 2500 / 3500**

1 - Driver Side Bracket  
1 - Passenger Side Bracket  
4 - 5/16" x 1.5" Allen Head Bolts  
4 - 5/16" Nuts  
6 - 5/16" Washers

## PRE-INSTALLATION

**Professional installation by a certified technician is strongly recommended.**

*Not responsible for altered products. No claims are made regarding any after-market devices. Any and all claims implied in this document excluded.*

### NOTES:

This bracket kit installation requires the removal of the headliner from the vehicle. This will include interior trim pieces, lighting, visors, etc. Be careful when moving side curtain airbags (if installed) and do not unplug them.

Light bar not included in kit.

### REQUIRED TOOLS:

Socket Set	Allen Wrenchs	Drill	3/8" Drill Bit
Tape Measure	Masking Tape	Permanent Marker	Silicone

## INSTALLATION INSTRUCTIONS

**STEP 1:** Disconnect positive battery lead before installation.

**STEP 2:** Apply masking tape to painted surface so brackets will not scratch paint.

**STEP 3:** Install brackets on 50" light bar (not included). Use hardware supplied with kit and hand tighten.

**STEP 4:** Position light bar and brackets in rain gutter toward windshield in desired location and mark mounting holes with marker or punch (2 outer holes per bracket - center hole may also be used to route wiring through roof).

**STEP 5:** Remove headliner from vehicle.

**STEP 6:** Remove brackets from vehicle. Drill holes with 3/8" drill bit. (Make sure to avoid wiring, airbags, etc.)

**STEP 7:** Remove tape from roof. Apply silicone around holes.

**STEP 8:** Place light bar assembly on roof and align brackets with mounting holes.

**STEP 9:** Insert mounting bolts from above and secure with washer and nut from inside vehicle.

**STEP 10:** Tighten all mounting hardware and light bar mount screws on each side.

**STEP 11:** Wire power to light bar per instructions supplied with kit.

**STEP 12:** Seal all holes and around wiring with silicone.

**STEP 13:** Reinstall headliner and trim pieces.

**STEP 14:** Reconnect positive battery lead.

## POST-INSTALLATION

**MAINTENANCE:** Periodically check to ensure that all fasteners are properly tightened.