INSTALLATION INSTRUCTIONS 4410 89 – 94 Toyota Pick Up Regular Cab 2WD	
QTY(1) Sidebar set (Driver & Passenger)(1) Hardware kit including : (4) 1/2 x 1 1/2" Hex head bolt(2) Front mounting brackets(4) 1/2 x 1 1/2" Hex head bolt(2) Rear mounting brackets(4) 1/2" Flat washer(4) Top/bottom clamps sets(4) 1/2" Lock washer(3) Flat brackets(8) 3/8 x 1 3/4" Hex head bolt(1) Channel bracket(8) 3/8" Lock washer(1) Square spacer(8) 3/8" Hex nut	
Tools Required :3/4" Socket9/16" SocketRatchet3/4" Wrench9/16" Wrench	Approximated installation time: 30 min.
<ol> <li>Read and understand instructions completely before beginning installation.</li> <li>Sidebar set consist of a driver and passenger side. Be sure to determinate the correct side before installation.</li> <li>Bolt mounting brackets to the sidebars as shown in Illustration using 1/2 x 1 1/2" hex head bolts, flat and lock washers.</li> <li>On the inside of the passenger side frame remove bolt holding plastic clip that supports brake and gas lines. Place the square spacer between the clip and the frame and reinstall bolt. <i>Note:</i> Remove only the clip nearest to the front of door.</li> <li>Position side bar up to the frame (end of the tube about 5" from back of door), slide top clamp between top of frame and body. Then hook top and bottom clamps into flat/channel brackets as shown. Bolt mounting brackets to the top/bottoms clamps using 3/8 x 1 3/4" hex head bolts, flat &amp; lock washers and hex nut. Leave loose. <i>Note:</i> Some adjustment front to back might be necessary to clear obstructions that might be on frame.</li> </ol>	
<ul> <li>6. Make any final adjustments to the alignment of the sidebar and tighten all bolts. Rep</li> <li>7. You may need to periodically re-tighten the bolts.</li> </ul> AssemblyDiagram : Channel bracket	Top clamp
(only rear passenger side) Square spacer (only front passenger side) Flat bracket	Rear mounting bracket 3/8 x 1 3/4" hex head bolts
	2 x 1 1/2" Hex ad bolt Front

Protect the finish with a non-abrasive automotive wax, (e.g. Pure Carnauba) on a regular basis. The use of any soap, polish, or wax that contains an abrasive is detrimental to the finish, as the compounds scracht the finish and cause corrosion.