



PRO COMP SUSPENSION, Inc. Chula Vista, CA USA

Ph:(619) 216-1444 ● Fax:(619) 216-1474 ● E-Mail: tech@explorerprocomp.com ● Website: www.explorerprocomp.com

INSTALLATION INSTRUCTIONS:

- ⇒ *PLEASE READ ALL INSTRUCTIONS FROM START TO FINISH BEFORE YOU BEGIN INSTALLATION*
- ⇒ *Secure and properly block rear wheels prior to installation.*
- ⇒ *Check hardware list to assure your kit is complete.*

Part # 58103
'73-'87 GM 4WD
Front Double
Shock Kit

BILL OF MATERIALS:

PART#	DESCRIPTION	QTY.
90-1001	Shock Bracket (Driver)	1 ea
90-1002	Shock Bracket (Passenger)	1 ea
90-2076	.750" x 1.25" Spacer	2 ea
90-2075	.750" x .31" Spacer	2 ea
90-6050	Hardware Pack Containing:	
70-0506001500	1/2" x 6" USS Gd 5 Hex Bolt	2 ea
70-0505501500	1/2" x 5 1/2" USS Gd 5 Hex Bolt	2 ea
70-0501501500	1/2" x 1 1/2" USS Gd 5 Hex Bolt	4 ea
72-05000100816	1/2" USS Stover Nut	8 ea
73-05000032	1/2" USS Flat Washer	8 ea

- 1) Remove front shocks.
- 2) Assemble upper shock mount and position shocks as shown in illustration. The **.312"** spacer will go between the original shock mount and the secondary shock. Use **6"** bolt for upper mounts.
- 3) Install **1.25"** spacer into factory lower shock mount and position shocks on both sides of lower mount. Use **5 1/2"** bolts for lower mounts.
- 4) Position upper shock mount so the new mounting holes are centered in the frame.

Tighten shock hardware at this time.

- 5) Drill through frame with 1/2" drill using the bracket as a template. Be sure to check inside of frame for tubing or wires. Relocate if needed.
- 6) Install 1/2" x 1 1/2" bolts and tighten.

NOTE: *Inspect factory lower shock mount for cracks or for insufficient weld from the factory. Additional welding may be required to support the load.*

