



JET POWER-FLO

Throttle Body Spacer Installation Instructions 1988-1993 Ford Mustang Part# 62121

1. Remove Air Intake assembly from throttle body.
2. Remove throttle linkage bracket.
3. Remove the 4 bolts from the throttle body.
4. Install the Jet Power-Flo throttle body spacer using one gasket between the throttle body and spacer and one gasket between the spacer and the manifold using the longer bolts and lock washers provided with your Jet Power-Flo throttle body spacer.
5. Reinstall the throttle linkage bracket using the original factory bolts.
6. Verify that the throttle linkage, cruise control and kick down cables are ***NOT*** binding and that the travel on the linkage is correct before you start the vehicle.
NOTE: In some instances, it may be necessary to re-adjust the cables for proper travel. Refer to a factory service manual for correct adjustment procedures.
7. Reinstall the Air Intake assembly.

Jet Performance Products, Inc.
17491 Apex Circle
Huntington Beach, CA 92647

714-848-5515

www.jetchip.com

Fax: 714-847-6290