



RockJock® Professional OffRoad Products presents:

## **CE-9067 & CE-9068 Leaf Spring Main Eye Bushing Kits**

**Installation Instructions**

Assemble bushing sets onto the Jeep with the grease fittings toward the outside, and the lock nuts on the inside. Use one washer on each side - one under the bolt head and one under the nut. Torque all of the bolts to 90 ft. lbs. Check torque on the bolts after 100 miles, and re-check periodically after that. Grease with multi-purpose chassis grease or moly lube. If you have any questions during the installation of this product please contact our technical department at (714) 528-6957.



Currie Enterprises / RockJock Professional Off Road Products  
382 N. Smith Ave., Corona, Ca. 92880  
Ph (714) 528-6957 - F (951) 549-0267  
[www.rockjock4x4.com](http://www.rockjock4x4.com)



RockJock® Professional OffRoad Products presents:

## **CE-9067 & CE-9068 Leaf Spring Main Eye Bushing Kits**

**Installation Instructions**

Assemble bushing sets onto the Jeep with the grease fittings toward the outside, and the lock nuts on the inside. Use one washer on each side - one under the bolt head and one under the nut. Torque all of the bolts to 90 ft. lbs. Check torque on the bolts after 100 miles, and re-check periodically after that. Grease with multi-purpose chassis grease or moly lube. If you have any questions during the installation of this product please contact our technical department at (714) 528-6957.



Currie Enterprises / RockJock Professional Off Road Products  
382 N. Smith Ave., Corona, Ca. 92880  
Ph (714) 528-6957 - F (951) 549-0267  
[www.rockjock4x4.com](http://www.rockjock4x4.com)

