



RockJock® Professional OffRoad Products presents:

CE-9038, CE-9039, CE-9040, CE-9081 Jeep YJ Heavy Duty Shackles

Installation Instructions

Assemble shackles onto the Jeep with the grease fittings toward the outside, and the lock nuts on the inside. Tighten the center brace first to 60 ft. lbs. (standard (non-boomerang) YJ rear shackles do not have a center brace!), then torque the shackle bolts to 50 ft. lbs. Check torque on the shackle bolts after 100 miles, and re-check periodically after that. Grease with multi-purpose chassis grease or moly lube. If you have any questions during the installation of this product please contact our technical department at (714) 528-6957.



Currie Enterprises / RockJock Professional Off Road Products

382 N. Smith Ave., Corona, Ca. 92880

Ph (714) 528-6957 - F (951) 549-0267

www.rockjock4x4.com



RockJock® Professional OffRoad Products presents:

CE-9038, CE-9039, CE-9040, CE-9081 Jeep YJ Heavy Duty Shackles

Installation Instructions

Assemble shackles onto the Jeep with the grease fittings toward the outside, and the lock nuts on the inside. Tighten the center brace first to 60 ft. lbs. (standard (non-boomerang) YJ rear shackles do not have a center brace!), then torque the shackle bolts to 50 ft. lbs. Check torque on the shackle bolts after 100 miles, and re-check periodically after that. Grease with multi-purpose chassis grease or moly lube. If you have any questions during the installation of this product please contact our technical department at (714) 528-6957.



Currie Enterprises / RockJock Professional Off Road Products

382 N. Smith Ave., Corona, Ca. 92880

Ph (714) 528-6957 - F (951) 549-0267

www.rockjock4x4.com

