



12302 Shiloh Church Rd.
Houston, TX 77066
Ph: (281) 880-6322

INSTALLATION GUIDE:

Part #s: F044RSP & F042LRSP

Hardware Bag Contents:

- 4) 1" x 1/2" Hex Bolts
- 4) 1/2" Nuts
- 8) 1/2" Large Flat Washers

Recommended Tools:

- 1/2" Wrench and Socket Wrench

Step 1. Locate the pre-existing factory bolt locations fastening the original bumper to the passenger & driver's side frame horns. **NOTE:** All pre-existing hardware attaching factory front bumper must be removed to un-apply original bumper.

Step 2. Once factory bumper has been removed completely, re-align N-FAB replacement front bumper back with the factory bolt hole locations. These two bolt locations per side will be vertical amongst the factory frame horn.

Step 3. Once the holes are aligned properly with the two holes located vertically from each other, please install each bolt into the appropriate mounting locations using a large flat washer on the front & back of N-FAB bracket plate.

Step 4. Please apply nut included in hardware kit to the back side of frame location to fasten bracket secure. **NOTE:** Bolt must be led through frame horn, followed by the large flat washer, and fastened between 15 - 20lbs torque rating. This concludes the installation.

Products licensed to N-FAB Inc by Fichter Designs are protected by US patent law and International Copy Right law. US Patent #6588783, #6874801, #7416202. Other patents and continuances pending. N-FAB products configuration also protected by International Trade Dress Law. All Design and Patent infringements will be prosecuted to the full extent of the law.

