



Bracket Cover

IN 595

Tools Required

- Diagonal Cutting Pliers
- Tape Measure
- Drill with Phillip Bit

Bracket Covers U channel plastic (Not End Caps)



- 1) For a Ford Super Duty truck notch top 1" x 1" cutting with diagonal cutter nipping about 1/4" at a time, or cut with saw if available.

Use (2) self tapping screws to secure to bracket.



- 2) For a GM truck cut down to 2 3/4" with diagonal cutter nipping about 1/4" at a time, or cut with saw if available.

Use (2) self tapping screws to secure to bracket.

Ford F150 and Ram trucks do not require plastic covers



Bracket Cover

IN 595

General Motors Truck



Ford Super Duty Truck

