

INSTALLATION INSTRUCTIONS

Rear Wheel Well Inner Liner

Ram 2009+

LIK-62



List of Contents:

1 Pc. Passenger's side Inner Wheel Well Liner



1 Pc. Installation Kit

20 pc. Plastic Push lock pin



1 Pc. Driver's side Inner Wheel Well Liner



1 pc. Installation Instructions.

Preparations:

Clean the interior panels of the rear Wheel house.

Installation time estimated: 20 min.

Instructions:

PLEASE READ INSTRUCTIONS CAREFULLY BEFORE STARTING THE INSTALLATION.

NOTE: One person can do the installation.

1. Starting on Passenger side locate the holes on the sheet metal, making sure no screws or push pins are present



2. Mount the Inner Wheel Well Liner marked as (PS) inside the inner panel of the wheel house.



3. Insert the bottom sides behind the metal flange .



4. Insert the upper section of the plastic liner behind the metal flange, make sure all the edges are inside the metal wheel well house edge.



Care and Maintenance Recommendations

To protect the appearance of this product, wash with soap and water

INSTALLATION INSTRUCTIONS

Rear Wheel Well Inner Liner

Ram 2009+

LIK-62



5. Locate the 2 pre-drilled holes on the front of the plastic Wheel Well and install one plastic push lock pin on each.



6. Locate pre-drilled holes on the body of the Inner Wheel Well Liner, align holes with pre-drilled holes located at the wheel house flange, then install one push lock pin in each hole.



To install Driver's side Inner Wheel Well Repeat steps 1 - 6

For trucks WITH factory Mud Flaps

- A.** Remove mud flaps before Inner Wheel Well Installation
- B.** Follow steps 1-8 to install Inner Wheel Well liner
- C.** Re-install the Mud Flap



Care and Maintenance Recommendations

To protect the appearance of this product, wash with soap and water