# Installation & CARE



INNOVATE

PERFESSIONA

SERVI

### 1998-2001 MERCEDES-BENZ M-CLASS W163 LED TAIL LIGHTS INSTALLATION INSTRUCTIONS

#### **BEFORE INSTALLATION:**

- If you experience any difficulties that the instructions did not cover, please seek assistance at a local automotive shop.
- · Please wear proper protective equipment before you work on any vehicle.
- · An assistant is recommended when removing the front bumper from your vehicle.
- · Please be cautious when working with the bumper or any parts belonging to the vehicle's body to prevent scratching.
- · Do not make direct contact with the halogen bulbs or the wire assembly until the unit has cooled down after use.

### TOOLS AND SUPPLIES REQUIRED



## PRODUCT NUMBER

LT-BW16398GLED-TM LT-BW16398RLED-TM LT-BW16398RGLED-TM



# LET'S START THE INSTALLATION



Remove the two 8mm tail light mounting nuts



Disconnect the tail light harness and remove the factory tail light housing



Connect the tail light harness



Seat the new tail light assembly in place



Reinstall the two 8mm tail light mounting nuts



Please repeat the steps from 1 to 5 for the opposite side



Close the trunk to complete installation



# Installation & CARE



INNOVATE

PERFESSIONAL

SERVIC

## 1998-2001 MERCEDES-BENZ M-CLASS W163 LED TAIL LIGHTS INSTALLATION INSTRUCTIONS

#### **BEFORE INSTALLATION:**

- · If you experience any difficulties that the instructions did not cover, please seek assistance at a local automotive shop.
- · Please wear proper protective equipment before you work on any vehicle.
- · An assistant is recommended when removing the front bumper from your vehicle.
- · Please be cautious when working with the bumper or any parts belonging to the vehicle's body to prevent scratching.
- Do not make direct contact with the halogen bulbs or the wire assembly until the unit has cooled down after use.

# 1998-2001 MERCEDES-BENZ M-CLASS W163 LED TAIL LIGHTS INSTALLATION INSTRUCTIONS

