

Hardware:	Qty
M8 x 25mm hex bolt	2
M8 washers	4
M8 Nuts	2
1'x1/2" Hex bolts	4
1/2" nuts	4
1/2" Washers	8
Parts Included:	Qty
RBS-H Bumper	1
Bumper Bracket	2
Bracket spacers	4



### **Rear Bumper Removal:**

**Step 1:** Unplug the connector that connects the bumper's wiring harness to the rest of the vehicle.




**Step 2:** Unplug the connector on the back of the trailer light plug. Press the two metal tabs together and push it out of the front of bumper.



**Step 3:** Remove the license plate bulbs from there housing and secure out of the way.

**Step 4:** Unbolt and remove the license plate and plastic retainer from the OE rear bumper.



**Step 5:** Remove the plastic end cap. (Both sides)




PART NUMBER: T14RBS-H  
PRODUCT: REAR BUMPER/HITCH  
APPLICATION: 14-17  
TOYOTA TUNDRA

**Step 6:** Remove the plastic bumper cap and set aside.



**Step 7:** Remove the four top bolts and two lower bolts that attach the bumper end and Remove. (Both sides)



Bottom

### **RBS-H Bumper Bracket Install:**

**Step 1:** Remove the two 19mm hitch bolts. (Both Sides)





**Step 2:** Remove the two bolts that attach the OE bumper bracket and remove (Bothe sides))



PART NUMBER: T14RBS-H  
 PRODUCT: REAR BUMPER/HITCH  
 APPLICATION: 14-17  
 TOYOTA TUNDRA

OE Bracket will not be re-used

**Step 3:** Using the two 21mm hitch bolts removed in step 1 and the supplied M8x25mm Hex bolt, nut and washers, install the bumper brackets with the spacers and tighten. (Both Sides)



**RBS-H Bumper Install:**

**Step 1:** Remove RBS-H bumper skid plate and set aside. Next, install the RBS-H bumper to the bumper brackets using the supplied 1/2"x1" hex bolts, nuts and washers.

12302



**Step 2:** After proper alignment, tighten all hardware. **NOTE: Carefully open tail gate to check clearance with bumper before final tightening.**

**Step 3:** Re-Install RBS-H skid plate and secure. **NOTE: An aftermarket license plate light is recommended.**