



SB008 INSTALLATION INSTRUCTIONS

TOOLS REQUIRED:

- Hydraulic jack and jack stands
- ½" and 9/16" wrench and socket

Installation Instruction

1. Raise the front of the car in the air and secure with jack stands.
2. Removed the front sway bars end links.
3. Remove the four (4) bolts holding the rear sway bar saddles on the frame with a ½" socket.
4. Install the sway bar bushings over the sway bar and press the saddles over the bushing.
5. Mount the sway bar saddles to the frame and the end links to the control arm. **Do not tighten.**
6. With the bar loose in the saddles, center the bar and ensure that there is clearance for the control arms and the steering linkages.
7. Tighten the sway bar saddle bolts.
8. Tighten the end links until the bushings compress.
9. Reinstall wheels and lower vehicle.



WWW.BMRSUSPENSION.COM

This product is an aftermarket accessory and not designed by the vehicle's manufacturer for use on this vehicle. As such, Buyer assumes all risk of any damage caused to the vehicle or person during installation or use of this product.