



BX2205 Installation Instructions 1984-85 Honda Accord

Installation of this baseplate requires removing the plastic belly pan.

1. Read the General Instruction Sheet included with this baseplate.
2. The tow bar consists of a permanently mounted baseplate, two tie down clamps, two bumper brackets and a detachable tow bar.
3. The baseplate mounts to the front underside of the vehicle using eight bolts, four on each side, using four which are provided and four existing,
4. Remove the plastic belly pan. The two plastic push pins at the front outside corners are removed by pulling down on the pin head with pliers.
5. Remove the two bolts which secure the front bumper to its mounting brackets. These bolts are accessible through holes in the plastic trim located just below the bumper.
6. Place a jack below the center of the engine support cross brace and raise it enough to hold the cross brace in position when removing the four bolts that secure it to the frame.
7. Remove the two bolts and inspect them for reuse. See General Instruction Sheet.
8. Position the baseplate by inserting the short tube on the baseplate into the metal core of the rubber cross brace bushing. Hand start the four cross brace bolts.
9. Using the 10mm bolts which are provided, loosely install the two bumper brackets through the holes in the plastic trim into the bumper. Note the right and left brackets.
10. Fasten the bumper brackets to the baseplate using the 3/8" bolts, lock washers and nuts which are provided.
11. Insert the small square part of the tie down clamps into the large upper end of the oblong hole in the tie down brackets on the vehicle. These brackets are stamped metal parts with an oblong hole facing downward and are welded to each side of the vehicle.
12. Slide the 1/2" spacer washers between the baseplate sides and the tie down bracket outer sides.
13. Install the 1/2" bolts, lock washers and nuts through this assembly.
14. When all bolts align, attach the baseplate to the vehicle.
15. Replace plastic belly pan.
16. The dimensional variations between otherwise identical vehicles can be considerable. While the location and size of the holes in the baseplate were designed to allow easy installation, it may be necessary to file a hole slightly to allow a bolt to clear.
17. Install the tow bar and safety cables according to the instructions included in their packages.
18. Do not substitute other devices if the tow bar pin and clip are lost.
19. **DEALERS AND INSTALLERS:** BE CERTAIN THE USER RECEIVES THE INSTRUCTION SHEET.

Automatic

Tools Required

3/4 Socket	10mm Socket	14mm Socket	17mm Socket
3/4 Open End Wrench	Jack	Pliers	Socket Extension

Parts List

Ref. No.	Qty.	Part No.	Description
1	1	61-3313	Tie Down Clamp, Passenger's Side
2	1	61-3314	Tie Down Clamp, Driver's Side
3	1	61-3326	Mount Bracket, Driver's Side
4	1	61-3327	Main Baseplate Assembly
5	1	61-3328	Mount Bracket, Passenger's Side
6	2	102-2930	Spacer Washer
7	2	201-0051	1/2-13 x 1 1/2 Hex Bolt
8	2	201-0427	10mm-1.25 x 100mm Hex Bolt/ 14mmHdHxBlt
9	4	201-0443	3/8-16 x 1 Hex Bolt
10	4	202-0003	3/8-16 Hex Nut
11	2	202-0005	1/2-13 Hex Nut
12	4	203-0010	3/8 Lock Washer
13	2	203-0012	1/2 Lock Washer
14	2	203-0104	10mm Lock Washer
	2	226-0046	Baseplate Safety Cable, 36" CL III (Not Shown)
	2	229-0359	Quicklink, 3/8, ZP (Not Shown)

