

PUTCO ELEMENT CHROME WINDOW VISOR INSTALLATION

***NOTE: This is not an in-channel product, it will install to the exterior of the window molding. Please disregard instructions on box.**

Congratulations on your purchase of a high quality PUTCO product. Should you need any application or technical assistance feel free to call us at:

1-800-247-3974

Monday-Friday 8:00 a.m.- 5:00 p.m. (Central Standard Time)

Contact your PUTCO dealer for other quality accessories.

PUTCO Inc. - 216 West First Street - Story City, Iowa 50248

PLEASE READ ALL INSTRUCTIONS BEFORE INSTALLATION AND TO CHECK TO SEE THAT ALL PARTS ARE INCLUDED.

Installation Instructions

- 1. Insure that the surface which the trim is to be applied is clean, dry and free of all oil, grease and wax. The application surface must also be warm, minimum temperature of 15°C (60°F)**
- 2. Wash area with clean water and then dry.**
- 3. Determine exact location of trim piece.**
- 4. Remove protective film from adhesive, align carefully and then press firmly to insure proper adhesion.**

Las Instrucciones de la instalación

- 1. Asegure que la superficie que el recorta deberá ser aplicado es limpio, seca y libre de todo petróleo, la grasa y la cera La superficie de la aplicación debe estar también tempature tibia y mínima de 15°C (60 F)**
- 2. Lave área con agua limpia y entonces seque.**
- 3. Determine la ubicación exacta de recorta el pedazo.**
- 4. Quite la película protectora del adheavivo, alinee con cuidado y entonces apriete para asegurar firmemente la adhesión apropiada.**

Instructions d'installation

- 1. Assurer que la surface qui le mince va être appliqué s'est propre, sécher et libérer de tout pétrole, toute graisse et toute cire. La surface d'application doit être aussi temperature chaude et minimum de 15°C (60 F)**
- 2. Laver le domaine avec l'eau propre et sécher alors.**
- 3. Déterminer l'emplacement exact de morceau mince.**
- 4. Enlever le film protectif de l'adhésif, aligner soigneusement et alors appuyer fermement pour assurer l'adhérence correcte.**

LIMITED WARRANTY

Putco guarantees it's Stainless Steel and Aluminum products against defects in workmanship and material for as long as you own your vehicle. Black products have a 90 day warranty on the painted surface. Any defects resulting from faulty material or workmanship will be warranted by Putco and repaired or replaced at our discretion. Putco assumes no extra labor costs. Damages caused by freight carriers, improper installation, misuse, collision, or neglect will not be warranted by Putco.