

25202

03-06 GMC

SIERRA

AIR DAM BILLET



25202

03-06 GMC

SIERRA

AIR DAM BILLET

03-06 GMC SIERRA (ALL)

Tools Required:

Phillips Screw Driver
Drill
1/16" Drill Bit

Hardware / Parts Included:

1 Billet Insert (6 bars)
4 #8 Screws (#6 Head)

Read and understand instructions before attempting installation

Step 1.

Center the billet insert in the air dam (between the tow hooks). Note the tabs welded to each end of the billet insert. Drill a 1/16" hole into the air dam aligned with each hole.

Step 2.

Align the insert to the holes in the air dam. Secure the insert to the air dam using the screws provided. Do not over tighten the screws. ***Thank you for purchasing a T-Rex Billet Grille.***

5/9/07