

Fit: 2018 - Current

Jeep Tubular Door Rear Part: JL04RD


Jeep Wrangler JL





TO AVOID BEING SCRATCHED, PLEASE PROTECT THE SURFACE OF THE TAILGATE VENT COVER CAREFULLY.

REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT.









60-180 min

Cutting Not Required

Drilling Not Required



support@trailfx.com





1 866 638 4870



POLISHED STAINLESS STEEL - LIMITED LIFETIME POWDER COATED BLACK - 3 YEARS



PLEASE USE SAFETY GLASSES & ENSURE TO BLOCK VEHICLE MOVEMENT DURING INSTALLATION PROCESS

REAR TUBULAR DOOR INSTALLATION PARTS LIST			
Qty	Part Description	Qty	Part Description
8	M8x25 Half Round Head Socket Hexagon Bolt	8	M8 Spring Washer
16	M8x16x1 Flat Washer	8	M8 Nuts

Hardware Part list Illustration (For Reference)



Page 1 of 5 Rev 031419

INSTRUCTION PROCEDURE

- 1. Assemble the doors as shown below.
- 2. Remove the factory installed rear door. Raise the rear tubular door up into place and align the (2) holes on the frame with the holes on car on the doors.
- 3. Close the door and debugging screws.
- 4. Fasten safety belt in doors
- 5. Install the OEM vehicle bolts
- 6. Installation completed.

A: Door Assembly

STEP 1



Install doors connection parts and the safety belt (4xM8x25 bolts, 8xM8 Flat washers, 4xM8 Spring washers, 4xM8 nuts)

STEP 2





Page 2 of 5 Rev 031419

STEP 3



Fix the door and be bugging screws.






Page **3** of **5** Rev 031419

STEP 6







Page **4** of **5** Rev 031419

PRODUCT CARE

- 1. Periodically check the product to ensure all fasteners are tight and components are intact.
- 2. Regular waxing is recommended to protect the finish of the product.
- 3. **Use ONLY Non-Abrasive automotive wax.** Use of any soap, polish or wax that contains an abrasive is detrimental and can scratch the finish leading to corrosion.
- 4. Aluminum polish may be used to polish small scratches and scuffs for **Stainless Steel finish.**
- 5. Mild soap may be used to clean the product for both Stainless Steel and Black finish.

FAQ's

1. Mounting bracket are not getting Installed properly.

In some cases Illustration images shown in Installation manual may not be the exactly same as per actual vehicle images ,also if Driver / Passenger side mounting brackets are very identical in the design, suggest referring Parts Identification guide to avoid fitment issue.

2. Products are thumping / rattling after installation.

Please ensure that all required mounting brackets / hardware's are installed & tighten correctly. Suggest using white lithium / regular grease between the metal to metal contact surfaces.

3. Missing / Excess Hardware.

Recheck hardware count as per the part list.

4. Product not installing properly.

Ensure make model year, cab length and bed size of your vehicle is listed in the application. All installation steps are followed correctly.

Check out these other TrailFX Products!!

www.TrailFX.com









Keystone Automotive Operations Inc. (KAO) warrants this product to be free of defects in material and workmanship at the time of purchase by the original retail consumer. KAO disclaims any other warranties, express or implied, including the warranty of fitness for a particular purpose or an intended use. If the product is found to be defective, KAO may replace or repair the product at our option, when the product is returned prepaid, with proof of purchase. Alteration to, improper installation, or misuse of this product voids the warranty. KAO's liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for any incidental or consequential loss or damage.

Page 5 of 5 Rev 031419