

WeatherTech®

LampGard® Installation Instructions

Important: Read these instructions before attempting installation. Professional Installation Recommended.

Items Included: Custom Film Set, Squeegee

Required for Installation: Spray Bottle, 70% Isopropyl Alcohol, Baby Shampoo, Water, Lint Free Cloth

1. Mix 1 part 70% Isopropyl alcohol to 3 parts water in a spray bottle.
2. Thoroughly clean the surface of the lenses using the alcohol and water solution. The lenses must be free of all contaminants such as grease, wax, tar and dirt. Dry with a lint free cloth.
3. Mix 1 part Baby shampoo to 3 parts water in a spray bottle to create a slip solution.
4. Before removing the templates from the paper backing, test each piece to assure proper fit.



Note: For best results, the lenses should be warm to the touch.

5. Using the slip solution of baby shampoo and water, spray your fingers to keep them wet during the process. Handling the adhesive with dry fingers will leave permanent visible marks.
6. Generously spray the lens you will be working on with the slip solution.
7. Carefully remove the LampGard template from the border and backing paper. Generously spray the slip solution onto the adhesive side.
8. Apply the LampGard onto the appropriate lens and align with the outer edges. The slip solution will allow the template to move around on the lens to the desired position.

Note: For a round or square lens, starting from the center and working out toward the edges work best, and for a curved lens, starting from the inner edge and working back toward the center works best.

9. Using the supplied squeegee, start from either the inner corner or center of the lens depending on the shape and use short firm strokes to force excess slip solution and air bubbles out to the edges of the LampGard template

Note: The material can stretch to form on the lens. If there is excess material beyond the edges of the lens once complete, it can be removed with a sharp blade.

Note: The LampGard may have a slightly hazy appearance after initial installation. This is caused by residual moisture being trapped under the film and is normal. The moisture will dissipate over a period of time depending on ambient temperature and humidity levels. With correct installation, the haziness should last no longer than two weeks. If too much solution was left beneath the LampGard and all the moisture has not evaporated by this time, there is no cause for concern because the drying time will simply take longer.

HELP!! If you have questions regarding installation of this or any other WeatherTech® product, please call our customer service department at (630) 769-1500. We want to help you get the most out of your new WeatherTech® product. Please visit our website at www.WeatherTech.com