Hoop II Multi-Mount Step Installation Instructions

Part No's: 102521 / 102522 / 102524 / 102527



Quality and Style that Endures

Follow the diagram and the written directions carefully for a proper, safe installation.
Should you encounter an unusual, unforeseen problem, contact our Technical Help Line 7:00 AM – 3:00 PM Pacific Time

(951) 719-1068

Visit our web-site at www.CARR.com
Warranty Information on our website
Carr Pattern Co.. Inc.

Vehicle Application:

FORD


81-96 F150, F250 light Duty PU, Bronco 81-98 F250-550 HD PU 95-96 F150 Lightning


MATERIAL NEEDED:

Drill motor, 3/8" drill bit, 1/8" drill bit, pencil, Phillips screw driver, center punch, two ½" wrenches, two 7/16" wrenches, and silicone.

MATERIAL FURNISHED:

Two castings, four zinc plated steel brackets, instruction page and two hardware packs (Important! Not all of the parts in these hardware packs may be needed for proper installation).







Hoop II Multi-Mount Step Installation Instructions

Part No's:102521 / 102522 / 102524 / 102527



WARNINGS!

- Do not over tighten the nuts and bolts or damage to the castings and or stripping of the threads could result.
- FOR SAFE AND PROPER USAGE OF THIS PRODUCT, THE MOUNTING INSTRUCTIONS MUST BE FOLLOWED CAREFULLY AND COMPLETELY.
- The manufacturer and distributor of this product are in no way responsible for the consumer's failure to adhere to the warnings and directions of these instructions in the event of damage to the consumer's vehicle, other properties and or personal injury.
- REFER TO DIAGRAM "A" WIRE HARNESS. STEP "12" ON THIS PAGE MUST BE FOLLOWED, IF NOT ELECTRICAL DAMAGE TO YOUR VEHICLE MAY OCCUR.
- For the proper position of the step, the front edge of the seat while in normal driving position should be in line with the center of the step. For personal preference or to avoid any obstruction underneath body metal, step can be moved left or right.
- Assemble the steel brackets to the step as shown in the diagram, but only hand tighten.
- When positioning the step against the body metal be sure to avoid all bumps and screws to make sure that the step is against a flat surface.
- When the desired location is found, while holding the step in that position, take a pencil and **ONLY** use the two 5/16" holes on each bracket as a guide and mark the holes on the underside of the body metal.
- 5. Center punch the marked holes.
- Take a 1/8" drill bit and drill out the centered punched holes.
- 7. Replace the 1/8" drill bit and drill out the 1/8" hole with a 3/8" drill bit.
- After drilling, make sure that all the burrs are removed.
- Remove the steel brackets from the step casting.
- 10. Place the steel brackets back on the vehicle where the two holes were drilled.
- 11. Use the 5/16" x 1" Carriage bolts to go through the 11" steel strap and the body metal and securely tighten the brackets to the vehicle. (See Diagram) The steel strap will be visible when door is open.
- 12. *REFER TO DIAGRAM "A" WIRE HARNESS. Remove the plastic cover that is holding the carpet down and move the wire harness out of the way before drilling out the hole for the next step as shown on the diagram. Do this procedure for both sides of your vehicle, because the wire harness may be on either side.
- 13. Take a 1/8" drill bit and drill a hole through the vehicle using the two top 1/4" holes on the step as a guide.
- 14. When drilling is complete, take the 5/8" sheet metal screws provided and securely tighten.
- 15. Re-install your carpet protectors with the screws that were removed.
- 16. Place the step back into the steel brackets with the 1/4" hardware provided and securely tighten.
- 17. Check again and securely tighten ALL hardware.
- 18. We advise putting silicone sealer around the areas where the aluminum mounting brackets contact the body metal.
- 19. After one month of use, go back and give all hardware a final tightening.

Carr Pattern Co., Inc. Warranty Policy

Finishes: Limited Lifetime Structural Warranty: Limited Lifetime Warranty Conditions:

- All warranties start from consumer's date of purchase.

- An Warranties start from Consumers state of purchase.
 A new product will be sent out immediately to replace a warranty claim.
 The above guidelines apply only to the Original Purchaser.
 Original proof of purchase must be submitted for all warranty and returns issues.

 Warranty Limitations:
- Warranty coverage extends ONLY to repair or replacement of the CARR product. This warranty does not cover the cost of labor, transportation, installation or removal of the product. Warranty coverage does not extend to damage caused by: collision, fire, theft, freezing, vandalism, riot, explosion or object striking the product, or misuse of the product and/or the vehicle on
- which the product is being installed.

 Warranty coverage does not extend to damage caused by: airborne fallout (chemicals, tree sap, etc.), stones, hail, earthquake, water or flood, windstorm, lightning, the application of chemicals or sealants subsequent to manufacture.
- Warranty coverage does not extend to damages caused by: normal wear and tear, abuse, modification or improper installation of the product.

 Warranty coverage does not extend to any economic loss or extra expense including (without limitation), payment for the loss of time or pay, inconvenience, storage, loss of vehicle use, vehicle rental expense, equipment rental expense, lodging, meals, or other travel costs.

This warranty gives you specific legal rights and you may also have other rights that vary from state to state. CARR does not authorize any person to create for it any other obligation or liability in connection with its products. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE APPLICABLE TO THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WRITTEN WARRANTY. PERFORMANCE OF REPAIRS AND NEEDED ADJUSTMENTS IS THE EXCULSIVE REMEDY UNDER THIS WRITTEN WARRANTY OR ANY IMPLIED WARRANTY. CARR SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM BREACH OF THIS WRITTEN WARRANTY.*

Some states do not allow limitations on how long an implied warranty will last or the exclusion or limitation of incidental or consequential damages, so that above limitations or exclusions may not

apply to you. Guarantee: Every attempt has been made to manufacture and distribute the finest quality products available. Our manufactured products are guaranteed to be free of defects due to workmanship or materials. Distributed products are subject to manufacturer's warranty only.