




TUNNEL BRACE / REAR DRIVESHAFT LOOP
INSTALLATION INSTRUCTIONS – Part # DTB002 and DSL011

Installation Instructions:

1. Lift vehicle and support with stands under the frame rails.
2. Using a 13mm ratchet, remove the 4 nuts and 2 bolts that retain the air deflectors and remove the deflectors.
3. Using the same socket, remove the factory tubular tunnel brace located directly forward of the air deflectors (05-2010 models only).
4. It is necessary to lower the exhaust in order to install the BMR tunnel brace. The exhaust does not need to be removed. Loosen the four (2 per side) 15mm bolts on the center of the exhaust.
5. Support the transmission with a hydraulic jack and then loosen all 4 transmission cross-member bolts. Lower the transmission cross-member until the exhaust is low enough to insert the BMR tunnel brace.
6. Once the brace is in place, thread the OE nuts and BMR provided hardware onto the factory studs and tighten all bolts/nuts to 20 ft/lbs.
7. If you are installing the cross-brace only, proceed to step 10 below. If you are installing the driveshaft loop, loop it over the shaft by positioning it over the small portion of the shaft.
8. Once it is straddling the driveshaft, bolt it down to the tunnel brace using the supplied nuts and bolts.
9. Center the loop to provided the best all-around clearance possible and tighten with a 9/16" wrench and socket.
10. Lift transmission and re-install the four mounting bolts. Torque to 55 ft/lbs.
11. Tighten the exhaust clamp bolts.
12. Lower vehicle.



WWW.BMRSUSPENSION.COM

This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, buyer assumes all risk of any damage caused to the vehicle/person during installation or use of this product.