

MSS Install Guide

Supplied for the Audi Q2/SQ2





f	0	
@MSSautomotive		

This short guide is intended for use with MSS Kit for the Audi Q2/SQ2

Refer to pages 3 and 4 of the latest version of the 'MSS INFO for Installer'

R5 MSS Ltd MSS House A3 Albion Daedalus Park Daedalus Drive Lee On The Solent Gosport Hampshire PO13 9FX United Kingdom Company No.09360144

<u>>|||||</u>

f O D @MSSautomotive

R5 MSS Ltd MSS House A3 Albion Daedalus Park Daedalus Drive Lee On The Solent Gosport Hampshire PO13 9FX United Kingdom Company No. 09360144



FRONT AXLE INSTALL PROCEDURE

This is best done with struts removed from the vehicle. Refer to the manufacturer's workshop manual for steps on how to safely remove the struts from the vehicle, remove and refit the springs and on the correct torque settings.

Difficulty Level: High

Estimated Time: 90 to 120 minutes per side, assuming the bolts are not seized. **Installing your new MSS Kit is best undertaken by an experienced VAG workshop/engineer.**

- 1. Remove the OE springs. These will be replaced by the MSS front system supplied.
- 2. Remove and keep the OE rubber dust boots. These will be re-used.
- 3. Keep the OE bump stop to reuse.
- 4. OPTIONAL: Fit the MSS protective sleeves over the MSS large adjuster and OE bearing for protection from dust.
- 5. Fit the MSS large adjuster flush to the flat grounded end of the orange spring.
- 6. Fit the OEM camberplate/strut bearing so that these sit against the open end of the MSS spring
- 7. Turn the MSS adjuster to take up any free play.
- 8. Use a spring compressor to reduce spring height and help secure the arrangement
- 9. Tighten to the correct torque using appropriate tools used to remove the camberplate
- 10. Set the adjuster to the desired position by grab & twist the knurled ring, you can always adjust later as required


or email **support@mss.company** for the latest copy, to measure the current ride height. **Assembly Video Youtube Link.**

PRE-INSTALL STEPS

INTRODUCTION

FRONT AXLE INSTALL PARTS LIST

Before you start installing your new MSS Kit, check if all parts listed below have been supplied:



2x Large adjusters - these are the larger of the two sets



2x OPTIONAL: Large protective sleeves - these fit around the large adjusters



2x Large diameter MSS orange springs - these fit the large adjusters



f 🔿 D @MSSautomotive R5 MSS Ltd MSS House A3 Albion Daedalus Park Daedalus Drive Lee On The Solent Gosport Hampshire PO13 9FX United Kingdom Company No.09360144

∑ []U]U]

f O D @MSSautomotive



REAR AXLE INSTALL PROCEDURE

For the rear stacked arrangement, refer to the latest version of the 'MSS INFO for Installer' guide or email **support@mss.company** for the latest copy.

Difficulty level: Medium

Estimated Time: 30 to 45 minutes per side, assuming the bolts are not ceased. **Installing your new MSS Kit is best undertaken by an experienced VAG workshop/engineer.**

- 1. Remove the OE spring and top rubber spring seat. Both are replaced with MSS parts.
- 2. Fit the black spring in the lower arm and place the coupler into it. Ensure that the 60mm sleeve is facing upwards to mate to the MSS slimmer orange springs where appropriate.
- 3. Fit the orange spring on top of the coupler that is sat on the black spring.
- 4. OPTIONAL: Fit the MSS protective sleeves over the adjuster for dust protection.
- 5. Place the rear top located adjuster on the top of the slimmer orange spring.
- 6. Place the MSS rubber slip mat on top of the adjuster. Ensure it sits flush against the vehicle body to cover the protruding hump. The rubber slip mat prevents metal-to-metal contact.
- Our stacked springs are a direct replacement for the factory single form springs. Therefore, no other OE parts are replaced during the rear axle install.
- 8. Tighten the suspension parts that had been removed. Refer to the manufacturer's workshop manual for steps on how to safely remove the struts from the vehicle, remove and refit the springs and on the correct torque settings.
- 9. Set the ride height to sit 5mm higher than the fronts when measured from fender edge to wheel hub centre.

Please be aware that this is a MUST DO.

POST INSTALL STEPS


Complete a 1-mile journey before setting the ride height and 4-wheel alignment. Refer to pages 3 and 4 of the latest version of the 'MSS INFO for Installer' guide for assistance on how to measure ride height.

NOTE: The rear axle ride height should be set to at least 5mm higher than the front axle ride height when measured as per page 3 of the latest version of the 'MSS INFO for Installer' guide. This is a KEY step.



REAR AXLE INSTALL PARTS LIST

2x Black MSS Springs these are common parts used for almost all our products



Before you start installing your new MSS Kit, check if all parts listed below have been supplied

2X Top located adjusters to couple the black and orange springs together and adjust height



2x Small diameter MSS

orange springs

to eliminate resonant road noise

travelling through the system


2x MSS supplied flat

rubber slip mats -



2x Couplers - for the orange and blacks springs

2x OPTIONAL: Small protective sleeves these fit around the combined adjusters



Adjuster spanner for both front and rear adjusters Triple Engineered Suspension for Ultimate Performance, Comfort & Safety

MSS Support Team

Telephone: +44 (0)20 3507 1973 (select appropriate option when prompted) Email: support@mss.company