



**Installation Instructions**  
**Front Bolt-On Look Fender Flares**  
**Chevy Silverado 5.8 FT 1500,2500,3500 (14-On)**  
**FF883**

**Important: Please read instructions entirely before installing this product.**

Hardware Included	QTY
U CLIP .6mm	10
Large CLIP .9mm	6
Screws 12g	6

Hardware Included	QTY
Alcohol Towelette	6
Abrasive resistant tape	4
Washers	6
E CLIP .6mm	2

Bolt Kit Included	QTY

Ensure that both left and right hand Fender Flares suit the profile of the vehicle. Note the areas where the Fender Flares come in contact with the vehicle. NOTE: Before fitting Fender Flares remove any moldings, strips or existing flares from the wheel arch. If there is a body side molding, mark where the molding is to be cut, alternatively the Fender Flare can be cut to go around the molding. Be sure to allow enough room for the extrusion. **No drilling of vehicle is required for Bolt-On Look Fender Flares. This is a non-drill product.**



**STEP 1:** Clean the body areas where the Fender Flares will make contact. Ensure fenders are dry prior to install. Turn tires outward for Fender Flare installation.

**STEP 2:** Place Fender Flare on the vehicle into the position of best fit. Note where the slots in Fender Flare at positions **A**, **B** and **C** align with the existing screws in the vehicle wheel arch. Remove Fender Flare. Remove the existing vehicle screws in location **A**, **B** and **C** using #15 Torx head screwdriver. Maintain screws for re-install.

For Technical Support/Warranty Information please call 909 923 7075

EGR Inc, 4000 East Graystone Drive, Ontario, CA 91761



**Installation Instructions**  
**Front Bolt-On Look Fender Flares**  
**Chevy Silverado 5.8 FT 1500,2500,3500 (14-On)**  
**FF883**



**STEP 3:** Using #15 Torx head screwdriver remove upper screw from the front factory mudguard. Maintain screws for re-install.



**STEP 4:** Apply clear tape to the inside edge of the fender wheel arch in front of positions **A, B and C (step 5)** over mastic sealant. Install the large brackets in positions **A, B and C (step 5)** aligning the slot in the bracket with the vacant holes from the factory screws in the vehicle wheel arch. Ensure clips are positioned over the clear tape. Re-install the factory screws in location **A, B and C** using a #15 Torx head screwdriver.



**STEP 5:** Place Fender Flare on the vehicle into the position of best fit so the slots in position **A** and **B** are over the holes in the front end of large clips. Ensure bottom rear slot in Fender Flare is located over the vacate hole in the factory mudguard. Apply upward tension on Fender Flare to the vehicle fender when installing the screws and washers provided into the clips in position **A** and **B** using a Philips head screwdriver.



**STEP 6:** Re-install factory screw in the mudguard using #15 Torx head screwdriver through the slot in the Fender Flare.

**For Technical Support/Warranty Information please call 909 923 7075**

**EGR Inc, 4000 East Graystone Drive, Ontario, CA 91761**



**Installation Instructions**  
**Front Bolt-On Look Fender Flares**  
**Chevy Silverado 5.8 FT 1500,2500,3500 (14-On)**  
**FF883**

**REAR FENDER FLARE INSTALLATION**



**STEP 7:** Clean the body areas where the Fender Flares will make contact. Ensure fenders are dry prior to install.



**STEP 8:** Using #15 Torx head screwdriver remove upper screw from the rear factory mudguard. Maintain screws for re-install.



**STEP 9:** To secure the Fender Flare to the body, apply upward tension on Fender Flare to the vehicle fender when installing the black metal clips. Slide the clips over the Fender Flare and the inner wheel arch lip in the five locations shown. Position the clip so that the barb in the clip locates in the slot of the Fender Flare.

**For Technical Support/Warranty Information please call 909 923 7075**

**EGR Inc, 4000 East Graystone Drive, Ontario, CA 91761**



**Installation Instructions**  
**Front Bolt-On Look Fender Flares**  
**Chevy Silverado 5.8 FT 1500,2500,3500 (14-On)**  
**FF883**



**STEP 16:** Install the "E" shape clip so that the clip slides over the inner sheet metal lip and is in line with the slot in the underside of Fender Flare. To secure the clip to Fender Flare apply inward tension on Fender Flare to the vehicle fender, position the clip so that the barb in the clip locates in the slot of the Fender Flare. Tighten previously loosened #15 torx screw in aero spoil.



**STEP 17:** Using #15 Torx head screwdriver re-install the upper screw from the rear factory mudguard through the slot in the Fender Flare. Ensure all fixing points are tight and secure and that the rubber seal is flush neatly against the vehicle body.

For Technical Support/Warranty Information please call 909 923 7075

EGR Inc, 4000 East Graystone Drive, Ontario, CA 91761