



B-BODY DRIVESHAFT LOOP INSTALLATION
Part # DSL002

Tools Required:

Jack	Jack Stands
13mm wrench	15mm wrench
6mm Allen wrench	10mm wrench

Installation:

1. Lift vehicle and support with jack stands under the frame rails.
2. Remove the driveshaft and tape the cups onto the u-joint to avoid needle-bearing loss.
3. Using the 13mm wrench, remove the OE chassis brace that is located just behind the transmission tail shaft.
4. Using the 15mm wrench, remove the bolts from the drivers' side exhaust flange and temporarily lower the exhaust.
5. Place the driveshaft loop into position where the OE brace was bolted with the loop facing upwards. Insert bolts and tighten.
6. Reinstall the driver's side exhaust pipe and tighten bolts. Reinstall the driveshaft and tighten bolts. Lower car.



WWW.BMRFABRICATION.COM

This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, Buyer assumes all risk of any damage caused to the vehicle or person during installation or use of this product.

