



Running Board

Part No. R0005RB/R0014MK



Fits: 2013 - Current
2013 - 2016


NISSAN PATHFINDER
INFINITI QX60



REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT.



READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.



DO NOT OVER TORQUE. STANDARD OPERATING LOAD FOR TIGHTEN BODY MOUNT NUTS & BOLTS VARIES FROM **45 TO 65** FOOT POUND.



60-180 min



Cutting Not Required



Drilling Not Required



support@trailfx.com




1 866 638 4870



POLISHED STAINLESS STEEL – LIMITED LIFETIME
POWDER COATED BLACK – 3 YEARS


PARTS LIST:

Qty	Part Description	Qty	Part Description
2	Running Boards	4	Front and Rear Locking Plates
1	Driver/Left Front Mounting Bracket	2	Long Center Locking Plates
1	Passenger/Right Front Mounting Bracket	2	10mm Double Bolt Plates
1	Driver/Left Front Long Inner Support Bracket	18	10mm Low Profile Single Bolt Plates
1	Passenger/Right Front Short Inner Support Bracket	18	10mm Plastic Retainers
2	Front "L" Outer Support Brackets	22	10mm x 27mm OD x 3mm Flat Washers
1	Driver/Left Center Mounting Bracket	22	10mm Lock Washers
1	Passenger/Right Center Mounting Bracket	22	10mm Hex Nuts
2	Center Support Brackets	8	8-1.25mm x 30mm Hex Bolts
1	Driver/Left Rear Frame Mounting Bracket	20	8mm x 28mm OD x 3mm Flat Washers
1	Passenger/Right Rear Frame Mounting Bracket	12	8mm Lock Washers
1	Driver/Left Rear Mounting Bracket	12	8mm Hex Nuts
1	Passenger/Right Rear Mounting Bracket	12	6-1.0mm x 20mm T-Bolts
1	Driver/Left Rear "7" Outer Support Bracket	12	6mm x 22mm OD x 2mm Flat Washers
1	Passenger/Right Rear "7" Outer Support Bracket	12	6mm Lock Washers
		12	6mm Hex Nuts




INSTALLATION PROCEDURE:

1. Start installation on the passenger side of the vehicle. Locate and remove the (2) rubber plugs in the bottom of the outer frame channel closest to the front wheel opening, **(Figure 1)**.




2. Select (2) 10mm Bolt Plates and (2) 10mm Plastic Retainers, **(Figure 2A)**. Partially thread the Retainers onto the Bolt Plates. **NOTE:** The Plastic Retainer is designed to help hold the Bolt Plate in place during Bracket installation.



(Fig 2A) 10mm Bolt Plate w-Retainer

3. Insert (1) Bolt Plate into the first-forward hole with the plate pointed toward the rear of the vehicle, (**Figure 2B**). Thread the Plastic Retainer down tight against the body panel. Repeat to install the next Bolt Plate into the second hole with the Plate pointed toward the front of the vehicle, (**Figures 2B & 3**). **IMPORTANT:** The Plates on the (2) Bolt Plates must be pointed toward each other, (**Figure 3**). Repeat this **Step** for all (6) Lock Plate installations.



(Fig 2B) 10mm Bolt Plates w-Retainers




Fig 3

Front or Rear
Lock Plate

4. Select (1) Front or Rear Lock Plate, (**Figure 3**). Slide the Lock Plate over the (2) Bolt Plates with the bent side toward the pinch weld. Attach the Lock Plate to the rear Bolt Plate only with (1) 10mm Flat Washer, (1) 10mm Lock Washer and (1) 10mm Hex Nut, (**Figure 4**). Tighten the Hex Nut at this time.




Fig 3


Front or Rear
Lock Plate




Fig 4

10mm Flat Washer
10mm Lock Washer
10mm Hex Nut



Front

5. Locate the round hole in the back of the outer frame channel directly behind the previously installed Bolt Plates, (**Figures 1 & 5**). Remove the rubber plug. Select (1) 10mm Bolt Plate and (1) 10mm Plastic Retainer, (**Figure 2A**). Partially thread the Retainer onto the Bolt Plate. Insert the Bolt Plate into the hole and tighten the Retainer as previously described in **Step 4**. Repeat this **Step** for all (6) single Bolt Plate installations.

IMPORTANT: Mounting areas may be covered with undercoating. Scrape excess undercoating from body panel at all mounting locations. Brackets must mount flat against body panels.



6. Select (1) Front "L" Support Bracket, **(Figure 6A)**. Attach the shorter leg on the Support Bracket to the front Bolt Plate with (1) 10mm Flat Washer, (1) 10mm Lock Washer and (1) 10mm Hex Nut, **(Figure 6B)**. Leave hardware loose at this time.



7. Select the passenger side Front Mounting Bracket. Attach the Bracket to the Bolt Plate in the back of the frame channel first with (1) 10mm Flat Washer, (1) 10mm Lock Washer and (1) 10mm Hex Nut, **(Step 6, Figure 7)**. Attach the Mounting Bracket to the back of the previously installed "L" Support Bracket with (1) 8mm x 30mm Hex Bolt, (2) 8mm Flat Washers, (1) 8mm Lock Washer and (1) 8mm Hex Nut, **(Figures 7 & 8)**. Do not tighten hardware at this time.

10mm Flat Washer
10mm Lock Washer
10mm Hex Nut




Fig 7

10mm Flat Washer
10mm Lock Washer
10mm Hex Nut






Fig 8

8mm x 30mm Hex Bolt
(2) 8mm Flat Washers
8mm Lock Washer
8mm Hex Nut

8. Select (1) 10mm Bolt Plate and (1) 10mm Plastic Retainer, (Figures 2A & 9). Partially thread the Retainer onto the Bolt Plate.



(Fig 2A) 10mm Bolt Plate w-Retainer




(Fig 9) 10mm Bolt Plate w-Retainer

9. Next, locate the factory holes in the bottom of the inner frame channel directly behind the tie down loop where the frame is joined together. Insert the Bolt Plate, (as per Step 4), into the correct factory hole:
Passenger side installation: Use the 2nd factory hole back from the loop, (Figures 11 & 12).
Driver side installation: Use the factory hole closest to the tie down loop, (Figure 13).

10mm Bolt Plate
10mm Plastic Retainer
10mm Flat Washer
10mm Lock Washer
10mm Hex Nut

Passenger/right inner location pictured. Install Bolt Plate in 2nd hole behind tie down loop



(Fig 11) Passenger/Right inner location pictured. Bolt Support Bracket to back of Front Bracket






Fig 12

8mm x 30mm Hex Bolt
(2) 8mm Flat Washers
8mm Lock Washer
8mm Hex Nut



(Fig 13) Driver/Left front inner location pictured. Use hole closest to tie down loop


10. Select the correct Inner Front Support Bracket, (Figure 10). Attach the 90-degree bent end of the Support Bracket to the Bolt Plate in the frame channel with (1) 10mm Flat Washer, (1) 10mm Lock Washer and (1) 10mm Hex Nut, (Figures 11 & 13).




(Fig 10) Front Inner Support Brackets pictured from above

10mm Bolt Plate
10mm Plastic Retainer
10mm Flat Washer
10mm Lock Washer
10mm Hex Nut

Passenger/right inner location pictured. Install Bolt Plate in 2nd hole behind tie down loop



(Fig 11) Passenger/Right inner location pictured. Bolt Support Bracket to back of Front Bracket



(Fig 13) Driver/Left front inner location pictured. Use hole closest to tie down loop

11. Bolt the outer end of the Support Bracket to the front Mounting Bracket with (1) 8mm x 30mm Hex Bolt, (2) 8mm Flat Washers, (1) 8mm Lock Washer and (1) 8mm Hex Nut, (Figures 12 & 13).





Fig 12

8mm x 30mm Hex Bolt
 (2) 8mm Flat Washers
 8mm Lock Washer
 8mm Hex Nut

10mm Bolt Plate
 10mm Plastic Retainer
 10mm Flat Washer
 10mm Lock Washer
 10mm Hex Nut



(Fig 13) Driver/Left front inner location pictured. Use hole closest to tie down loop


Tie down loop

Bolt driver side Support Bracket to front side of front Bracket

12. Attach the passenger side Inner Support Bracket to the **back** of the Front Mounting Bracket, (Figures 11 & 12).

10mm Bolt Plate
 10mm Plastic Retainer
 10mm Flat Washer
 10mm Lock Washer
 10mm Hex Nut

Passenger/right inner location pictured. Install Bolt Plate in 2nd hole behind tie down loop



(Fig 11) Passenger/Right inner location pictured. Bolt Support Bracket to back of Front Bracket





Fig 12


8mm x 30mm Hex Bolt
 (2) 8mm Flat Washers
 8mm Lock Washer
 8mm Hex Nut

Attach the driver side Inner Support Bracket to the **front** of the Front Mounting Bracket, (Figure 13). Do not tighten hardware at this time.




(Fig 13) Driver/Left front inner location pictured. Use hole closest to tie down loop

13. Move along the side of the vehicle to the approximate center where the doors meet. Locate and remove the (2) rubber plugs from the bottom of the outer frame channel. Repeat **Steps 3—5** to install (2) Bolt Plates and (1) Long Center Lock Plate to the bottom of the frame channel, (**Figures 14 & 15**).




(Fig 14) Passenger side center location




(Fig 15) Passenger side Center Lock Plate


14. Next, locate the single hole in the back of the outer frame channel, (**Figure 16B**). Remove rubber plug if equipped. Select (1) 10mm Bolt Plate and (1) 10mm Plastic Retainer, (**Figures 2A & 9**). Install the Bolt Plate and Retainer in the back of the frame channel as previously described in **Steps 4 & 6**, (**Figure 16B**).





(Fig 2A) 10mm Bolt Plate w-Retainer




(Fig 9) 10mm Bolt Plate w-Retainer




15. Select (1) Center Support Bracket, **(Figure 16A)**. Attach the long end of the Support Bracket to the forward Bolt Plate in the frame channel with (1) 10mm Flat Washer, (1) 10mm Lock Washer and (1) 10mm Hex Nut, **(Figures 16B & 18)**. Select the passenger side Center Bracket, **(Figure 17)**. Attach the Bracket to the Bolt Plate in the back of the frame channel, **(Step 15)**, with (1) 10mm Flat Washer, (1) 10mm Lock Washer and (1) 10mm Hex Nut. Bolt the Center Bracket to the Support Bracket with (1) 8mm x 30mm Hex Bolt, (2) 8mm Flat Washers, (1) 8mm Lock Washer and (1) 8mm Hex Nut, **(Figure 18)**. Do not tighten hardware at this time.





10mm Flat Washer
10mm Lock Washer
10mm Hex Nut




10mm Flat Washer
10mm Lock Washer
10mm Hex Nut


8mm x 30mm Hex Bolt
(2) 8mm Flat Washers
8mm Lock Washer
8mm Hex Nut

Fig 18


16. Move to the rear mounting location in front of the passenger side rear tire opening. Locate the large oval and round holes in the inner body panel in front of the rear tire, **(Figure 19)**. Select (1) 10mm Double Bolt Plate and (1) 10mm Plastic Retainer, **(Figure 20A)**. Insert the Bolt Plate into the oval hole and up and out of the smaller round hole above it. Thread the Plastic Retainer onto the Bolt Plate over the top round hole to hold the Bolt Plate in place, **(Figure 20B)**.



(Fig 19) Passenger side rear mounting location pictured. Remove factory rubber plugs




(Fig 20B) Insert Double Bolt Plate into oval hole first, then up and out top hole. Passenger side rear mounting location pictured




(Fig 20A) 10mm Double Bolt Plate

17. Locate the last (2) round holes along the floor panel, **(Figure 19)**. Repeat **Steps 3—5** to install the (2) Bolt Plates and Rear Lock Plate, **(Figures 21 & 22)**. **NOTE:** Attach the Lock Plate to the front Bolt Plate only with

(1) 10mm Flat Washer, (1) 10mm Lock Washer and (1) 10mm Hex Nut, **(Figure 22)**. Tighten the Hex Nut at this time.




(Fig 19) Passenger side rear mounting location pictured. Remove factory rubber plugs



(2) 10mm Bolt Plates w-Retainers

Fig 21

**10mm Flat Washer
10mm Lock Washer
10mm Hex Nut**



(Fig 22) Passenger rear Lock Plate installation

18. Select the passenger side rear Frame Bracket, **(Figure 23)**. Attach the Frame Bracket to the Double Bolt Plate with (2) 10mm Flat Washers, (2) 10mm Lock Washers and (2) 10mm Hex Nuts, **(Figure 24)**. Do not tighten hardware at this time. Next, attach the driver side Rear Mounting Bracket to the front of the Frame Bracket with (2) 8mm Flat Washers, (2) 8mm Lock Washers and (2) 8mm Hex Nuts, **(Figure 25)**. Do not tighten hardware at this time.





Fig 23

**(2) 10mm Flat Washers
(2) 10mm Lock Washers
(2) 10mm Hex Nuts**




(Fig 24) Passenger rear Frame Bracket installation




(2) 8mm Flat Washers
 (2) 8mm Lock Washers
 (2) 8mm Hex Nuts

(Fig 25) Passenger rear Mounting Bracket

19. Select the passenger side "7" Rear Support Bracket, (Figures 6A & 26). Attach the Support Bracket to the rear Bolt Plate with (1) 10mm Flat Washer, (1) 10mm Lock Washer and (1) 10mm Hex Nut, (Figure 27). Do not tighten hardware. Attach the Mounting Bracket to the back of the "7" Rear Support Bracket with (1) 8mm x 30mm Hex Bolt, (2) 8mm Flat Washers, (1) 8mm Lock Washer and (1) 8mm Hex Nut, (Figure 27). Do not tighten hardware at this time.




(Fig 6A) Side view of Outer Support Brackets



(Fig 26) Pictured from below to show bends


8mm x 30mm Hex Bolt
 (2) 8mm Flat Washers
 8mm Lock Washer
 8mm Hex Nut

10mm Flat Washer
 10mm Lock Washer
 10mm Hex Nut



(Fig 27) Passenger side rear Bracket pictured from below

20. Carefully un-wrap the Running Boards. Insert (6) 6mm T-Bolts into the open ends of the channels, (3 T-Bolts per channel), in the bottom of the Running Board, **(Figure 28)**. Hold the Running Board up in the approximate position and slide the T-Bolts down the channels to line up with the (3) Brackets. Tilt the Running Board up at a slight angle to clear the slots in the Brackets. Secure the Running Board to the Brackets with (6) 6mm Flat Washers, (6) 6mm Lock Washers and (6) 6mm Hex Nuts, **(Figure 29)**. **NOTE:** The Running Board is designed to fit close to the vehicle. It may be necessary to loosen the Mounting Brackets and tilt the Brackets downward to insert the Running Board. Do not fully tighten hardware at this time.



(Fig 28) Slide T-Bolts into open end of channels

8mm x 30mm Hex Bolt
(2) 8mm Flat Washers
8mm Lock Washer
8mm Hex Nut

6mm T-Bolts
6mm Flat Washers
6mm Lock Washers
6mm Hex Nuts




Fig 29

21. Level and adjust the Running Board and tighten all hardware.
22. Repeat **Steps 2—22** for driver side Running Board installation.
23. Do periodic inspections to the installation to make sure that all hardware is secure and tight.




Complete Installation

PARTS IDENTIFICATION GUIDE

Driver Side tube packed using "Green" color foam sheet. Passenger Side tube packed using "White" color foam sheet

No.	Parts Identification
1	Passenger / Right 'Rear' Bracket marked "PR"
2	Driver / Left 'Rear' Bracket marked "DR"
3	Passenger / Right 'Center' Bracket marked "PC"
4	Driver / Left 'Center' Bracket marked "DC"
5	Passenger / Right 'Front' Bracket marked "PF"
6	Driver / Left 'Front' Bracket marked "DF"

**Note:**

- This guide is to identify the parts and not a reference for part count.
- For part count, refer Parts List.
- Product / Bracket image is representative and actual design may vary.

PRODUCT CARE

- Periodically check the product to ensure all fasteners are tight and components are intact.
- Regular waxing is recommended to protect the finish of the product.
- **Use ONLY Non-Abrasive automotive wax.** Use of any soap, polish or wax that contains an abrasive is detrimental and can scratch the finish leading to corrosion.
- Aluminum polish may be used to polish small scratches and scuffs for **Stainless Steel finish.**
- Mild soap may be used to clean the product for both **Stainless Steel and Black finish.**

FAQ's**1. Hardware's are not of correct size.**

In GMC / Chevrolet truck model 2006 & up, customer needs to reuse the factory body bolts to install the bracket. If your vehicle is not GMC / Chevrolet 2006 & up, ensure that holes are not partially covered with any plastic grommet or rust? If it is, remove the plastic grommet & rust from the thread holes & re-try the installation.

2. Mounting Bracket are not getting Installed properly.

In some cases Illustration images shown in Installation manual may not be the exactly same as per actual vehicle images ,also if Driver / Passenger side mounting brackets are very identical in the design, suggest referring Parts Identification guide to avoid fitment issue.

3. Products are thumping / rattling after installation.

Ensure that all required mounting brackets / hardware's are installed & tighten correctly. Suggest using white lithium / regular grease between the metal to metal contact surfaces.

4. Side Bar is not aligning with vehicle / Step Pads are not aligning with vehicle doors.

Side bar may be interchanged or mounting brackets are not installed at the correct position in the vehicle. Refer Parts identification guide.

5. Missing / Excess Hardware.

Recheck hardware count as per the part list.

6. Product not installing properly.

Ensure make model year, cab length and bed size of your vehicle is listed in the application. All installation steps are followed correctly.

Check out these other TrailFX Products!!

www.TrailFX.com



BULL BAR



GRILLE GUARDS



BED RAILS



RUNNING BOARDS

Keystone Automotive Operations Inc. (KAO) warrants this product to be free of defects in material and workmanship at the time of purchase by the original retail consumer. KAO disclaims any other warranties, express or implied, including the warranty of fitness for a particular purpose or an intended use. If the product is found to be defective, KAO may replace or repair the product at our option, when the product is returned prepaid, with proof of purchase. Alteration to, improper installation, or misuse of this product voids the warranty. KAO's liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for any incidental or consequential loss or damage.