




Running Board

Part No. RBT002B



Fits: 2009 - 2014


Ford F150 Super crew Cab



REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT.




READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.



DO NOT OVER TORQUE. STANDARD OPERATING LOAD FOR TIGHTEN BODY MOUNT NUTS & BOLTS VARIES FROM 45 TO 65 FOOT POUND.



60-180 min



Cutting Not Required



Drilling Not Required



support@trailfx.com




1 866 638 4870



POLISHED STAINLESS STEEL - LIMITED LIFETIME
POWDER COATED BLACK - 3 YEARS


PARTS LIST:

Qty	Part Description	Qty	Part Description
1	Driver/left side Steel Running Board	10	8-1.25mm x 25mm Hex Bolts
1	Passenger/right side Steel Running Board	10	8mm x 28mm x 3mm Flat Washers
2	Driver/left Front or Rear Mounting Brackets	20	8mm x 24mm x 2mm Flat Washers
2	Passenger/right Front or Rear Mounting Brackets	20	8mm Lock Washers
1	Driver/left Center Mounting Bracket	6	6mm Double Bolt Plates
1	Passenger/right Center Mounting Bracket	12	6mm x 22mm x 2mm Flat Washers
10	8mm Deep Clip Nuts	12	6mm Lock Washers
10	8-1.25mm x 30mm Hex Bolts	12	6mm Hex Nuts



INSTALLATION PROCEDURE:


1. Starting on the passenger side of the vehicle, locate the (2) holes in the bottom of the body panel, (through pinch weld). Next locate the rectangular opening and (2) small holes in the inner body panel directly above the holes in the pinch weld, **(Figures 1 & 2)**. **NOTE:** The holes in the inner panel may be covered with sealing tape or insulation.
2. Slide (2) 8mm Clip Nuts into the rectangular opening with the nut towards the inside. Line up the threaded nuts on the clip with the round holes toward the front of the vehicle, **(Figure 2)**. **NOTE:** If necessary, hold a mounting Bracket up in position to determine correct factory mounting holes to use.
3. Select (1) Passenger/right front Mounting Bracket. Attach the Bracket to the (2) Clip Nuts with the included (2) 8mm x 30mm Hex Bolts, (2) 8mm Lock Washers and (2) 8mm x 28mm Large Flat Washers, **(Figure 3)**. Depending on model and year, the brake cable may be run on the inside or outside of the Bracket. Do not tighten hardware at this time.
4. Align the bottom holes in the front Bracket with the (2) holes in the pinch weld. Attach the Bracket to the pinch weld using the included (2) 8mm x 25mm Hex Bolts, (4) 8mm x 24mm Small Flat Washers, (2) 8mm Lock Washers and (2) 8mm Hex Nuts, **(Figures 4 & 5)**. **NOTE:** Insert the bolts up from the bottom of the pinch weld and through the Bracket.
5. Next, move toward the center of the vehicle. Locate the (2) holes in the pinch weld similar to the front location, **(Figures 1 & 6)**. Locate the rectangular slot and single round hole. Repeat **Steps 2—5** to install the Passenger side Center Bracket, **(Figures 7 & 8)**. **IMPORTANT:** The center Brackets look similar but each one is unique. Use the illustration above to determine the passenger center Bracket.
6. Continue along the cab to the rear mounting location. Locate the last (2) mounting holes in the pinch weld towards the back of the cab, **(Figure 1)**. Repeat **Steps 2—5** to install the rear mounting Bracket.
7. Select the passenger side Running Board. Place the Running Board on top of the Brackets.
8. Select (3) 6mm Double Bolt Plates, **(Figure 9)**. Locate the channels in the bottom of the Running Board. Insert the Bolt Plates into the channels in the bottom of the Running Board closest to the Brackets **(Figure 10)**. Lift the Running Board up and guide the studs through the Brackets.
9. Attach the Running Board to the Brackets with (6) 6mm Flat Washers, (6) 6mm Lock Washers and (6) 6mm Hex Nuts, **(Figures 11 & 12)**. **NOTE:** The Running Board is designed to fit close to the vehicle. It may be necessary to loosen the Bracket hardware and tilt the Brackets downward to insert the Running Board between the Brackets and the body. Do not tighten hardware at this time.
10. Level and adjust the Running Board as desired and tighten all hardware.
11. Repeat **Steps 2—11** for the passenger side Running Board installation.
12. Do periodic inspections to the installation to make sure that all hardware is secure and tight.

Driver Side Installation Pictured



(Fig 2) Slide 8mm Clip Nuts over holes


- (2) 8mm x 30mm Hex Bolts
- (2) 8mm Lock Washers
- (2) 8mm x 28mm Flat Washers




(Fig 3) Passenger/right front or rear Bracket attached to body panel

Passenger Side Installation Pictured

- (2) 8mm x 25mm Hex Bolts
- (4) 8mm x 24mm Small Flat Washers
- (2) 8mm Lock Washers
- (2) 8mm Hex Nuts




(Fig 4) Passenger/right front or rear Bracket attached to pinch weld




(Fig 5) Passenger/right front Bracket installed

- (2) 8mm x 30mm Hex Bolts
- (2) 8mm Lock Washers
- (2) 8mm x 28mm Flat Washers

- (2) 8mm x 25mm Hex Bolts
- (4) 8mm x 24mm Flat Washers
- (2) 8mm Lock Washers
- (2) 8mm Hex Nuts




(Fig 7) Passenger/right center Bracket



(Fig 6) Passenger/right center mounting location


Passenger Side Installation Pictured




(Fig 8) Passenger/right center Bracket installed



(Fig 9) 6mm Double Bolt Plate




(Fig 10) Slide 6mm Double Bolt Plate into channels



- (2) 6mm Flat Washers
- (2) 6mm Lock Washers
- (2) 6mm Hex Nuts

(Fig 10) Passenger/right side Bracket attached to Running Board illustrated



(Fig 11) Passenger/right side Bracket attached to Running Board



Complete Installation


PARTS IDENTIFICATION GUIDE

Driver Side tube packed using "Green" color foam sheet. Passenger Side tube packed using "White" color foam sheet

No.	Parts Identification
1	Passenger / Right 'Rear' Bracket marked "PR"
2	Driver / Left 'Rear' Bracket marked "DR"
3	Passenger / Right 'Center' Bracket marked "PC"
4	Driver / Left 'Center' Bracket marked "DC"
5	Passenger / Right 'Front' Bracket marked "PF"
6	Driver / Left 'Front' Bracket marked "DF"

Note:

- This guide is to identify the parts and not a reference for part count.
- For part count, refer Parts List.
- Product / Bracket image is representative and actual design may vary.

**PRODUCT CARE**

- Periodically check the product to ensure all fasteners are tight and components are intact.
- Regular waxing is recommended to protect the finish of the product.
- **Use ONLY Non-Abrasive automotive wax.** Use of any soap, polish or wax that contains an abrasive is detrimental and can scratch the finish leading to corrosion.
- Aluminum polish may be used to polish small scratches and scuffs for **Stainless Steel finish.**
- Mild soap may be used to clean the product for both **Stainless Steel and Black finish.**

FAQ's**1. Hardware's are not of correct size.**

In GMC / Chevrolet truck model 2006 & up, customer needs to reuse the factory body bolts to install the bracket. If your vehicle is not GMC / Chevrolet 2006 & up, ensure that holes are not partially covered with any plastic grommet or rust? If it is, remove the plastic grommet & rust from the thread holes & re-try the installation.

2. Mounting Bracket are not getting Installed properly.

In some cases Illustration images shown in Installation manual may not be the exactly same as per actual vehicle images ,also if Driver / Passenger side mounting brackets are very identical in the design, suggest referring Parts Identification guide to avoid fitment issue.

3. Products are thumping / rattling after installation.

Ensure that all required mounting brackets / hardware's are installed & tighten correctly. Suggest using white lithium / regular grease between the metal to metal contact surfaces.

4. Side Bar is not aligning with vehicle / Step Pads are not aligning with vehicle doors.

Side bar may be interchanged or mounting brackets are not installed at the correct position in the vehicle. Refer Parts identification guide.

5. Missing / Excess Hardware.

Recheck hardware count as per the part list.

6. Product not installing properly.

Ensure make model year, cab length and bed size of your vehicle is listed in the application. All installation steps are followed correctly.

Check out these other TrailFX Products!!

www.TrailFX.com



BULL BAR



GRILLE GUARDS



BED RAILS



RUNNING BOARDS

Keystone Automotive Operations Inc. (KAO) warrants this product to be free of defects in material and workmanship at the time of purchase by the original retail consumer. KAO disclaims any other warranties, express or implied, including the warranty of fitness for a particular purpose or an intended use. If the product is found to be defective, KAO may replace or repair the product at our option, when the product is returned prepaid, with proof of purchase. Alteration to, improper installation, or misuse of this product voids the warranty. KAO's liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for any incidental or consequential loss or damage.