




# D20LL2 2.0" Front Lift Leveling Kit



Fit: 1994-2001 Dodge Ram 1500 4WD  
 2006-2008 Dodge Ram 1500 4WD  
 1994-2012 Dodge Ram 2500/3500 4WD  
 2013 Dodge Ram 2500 4WD



REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT.



35" x 11.5"



support@trailfx.com



READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.



60-120 min



844-717-LIFT (5438)



Use the proper tools and safety equipment to perform all work. Torque all fasteners to proper specifications and double check work. Align your vehicle after installation.

### PARTS LIST:

Qty	Part Description	Qty	Part Description
6	Nuts 10mm X 1.25 mm		



1

Raise and support vehicle using jack stands or lift.



2

Remove Tires and set aside.



3

Support suspension with a floor jack.



4

Disconnect driver and passenger side lower sway bar links.



5

Remove lower shock mounting bolt located below spring.



6

Loosen all (3) upper shock tower mounting nuts. Leave on.



7

Slowly lower axle in order to remove shock and coil spring.



8

Remove spring towards the front of the vehicle.



9

Next, remove upper rubber spring isolator.



10

Then remove shock tower nuts and retaining plate.

Your new spacer replaces this retaining plate. Install it and reverse the order disassembly.

11

- ***Then reconnect lower shock bolt and tighten the upper shock mounting bracket.***
- ***Reinstall wheels/tires, lower to ground and torque.***
- ***Reconnect lower sway bar end-links and test drive.***
- ***Re-check all work performed and have vehicle aligned.***

**FINAL CHECKS & ADJUSTMENTS****Post Installation Check:**

- Once the vehicle is lowered to the ground, check all parts which have rubber or urethane components to insure proper torque.
- Torque wheels to factory specs.
- Move vehicle backwards and forwards a short distance to allow suspension components to adjust.
- Turn the front wheels completely left then right and verify adequate tire, wheel, brake line, and ABS wire clearance.
- Test and inspect steering, brake and suspension components for tightness and proper operation.
- Inspect brakes hoses and ABS lines for adequate slack at full extension.
- Test drive vehicle and re-check the torque of all fasteners and re-torque wheels on vehicle.

**NOTE:** Failure to perform the post inspection checks may result in vehicle component damage and/or personal injury or death to driver and/or passengers.

**Wheel Alignment/Headlamp Adjustment:**

- ✓ It is necessary to have a proper and professional wheel alignment performed by a certified alignment technician.
- ✓ Align the vehicle to factory specifications.
- ✓ It is recommended that your vehicle alignment be checked after any off-road driving.
- ✓ In addition to your vehicle alignment, for your safety and others, it is necessary to check and adjust your vehicle headlamps for proper aim and alignment.

**Vehicle Re-Torque and Safety Inspection:**

Upon completion of all services and adjustments performed on your vehicle, and within 50 miles of driving, check to ensure all fasteners and hardware are properly torqued to specification as noted in the vehicles factory service manual.

**Check out these other TrailFX Products!!**

www.TrailFX.com



Keystone Automotive Operations Inc. (KAO) warrants this product to be free of defects in material and workmanship at the time of purchase by the original retail consumer. KAO disclaims any other warranties, express or implied, including the warranty of fitness for a particular purpose or an intended use. If the product is found to be defective, KAO may replace or repair the product at our option, when the product is returned prepaid, with proof of purchase. Alteration to, improper installation, or misuse of this product voids the warranty. KAO's liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for any incidental or consequential loss or damage.