




F10RB1

1.0" Rear Lift Block Kit



Fit: 2004 – Current

Ford F150 2 & 4WD



REMOVE CONTENTS FROM BOX.
VERIFY ALL PARTS ARE PRESENT.



60-90 min



support@trailfx.com



READ INSTRUCTIONS CAREFULLY
BEFORE STARTING INSTALLATION.



844-717-LIFT (5438)



To be used with factory blocks. Includes longer U-bolts

PARTS LIST

Qty	Part Description	Qty	Part Description
4	U Bolt W: 3 3/4" L: 9 1/2"	2	Size: 2 1/2 X 5 M 1 X 5A Block
8	1/2" Nuts and Washers		



1

Raise and support rear frame of vehicle on level ground.




2

Disconnect rear lower shock from axle mount.



3

Work on one side of vehicle at a time, remove rear U-bolts.



4

Remove U-bolts and carefully lower axle.



5

Center lift block on axle pad under leaf spring pin side down.



6

Raise axle, install new U-bolts and hardware, and tighten.

- **Reconnect shock and lower vehicle to ground and torque U-bolts to factory specs.**
- **Test drive and check all work performed.**

**FINAL CHECKS & ADJUSTMENTS****Post Installation Check:**

- Once the vehicle is lowered to the ground, check all parts which have rubber or urethane components to insure proper torque.
- Torque wheels to factory specs.
- Move vehicle backwards and forwards a short distance to allow suspension components to adjust.
- Turn the front wheels completely left then right and verify adequate tire, wheel, brake line, and ABS wire clearance.
- Test and inspect steering, brake and suspension components for tightness and proper operation.
- Inspect brakes hoses and ABS lines for adequate slack at full extension.
- Test drive vehicle and re-check the torque of all fasteners and re-torque wheels on vehicle.

NOTE: Failure to perform the post inspection checks may result in vehicle component damage and/or personal injury or death to driver and/or passengers.

Wheel Alignment/Headlamp Adjustment:

- ✓ It is necessary to have a proper and professional wheel alignment performed by a certified alignment technician.
- ✓ Align the vehicle to factory specifications.
- ✓ It is recommended that your vehicle alignment be checked after any off-road driving.
- ✓ In addition to your vehicle alignment, for your safety and others, it is necessary to check and adjust your vehicle headlamps for proper aim and alignment.

Vehicle Re-Torque and Safety Inspection:

Upon completion of all services and adjustments performed on your vehicle, and within 50 miles of driving, check to ensure all fasteners and hardware are properly torqued to specification as noted in the vehicles factory service manual.

Check out these other TrailFX Products!!

www.TrailFX.com



Keystone Automotive Operations Inc. (KAO) warrants this product to be free of defects in material and workmanship at the time of purchase by the original retail consumer. KAO disclaims any other warranties, express or implied, including the warranty of fitness for a particular purpose or an intended use. If the product is found to be defective, KAO may replace or repair the product at our option, when the product is returned prepaid, with proof of purchase. Alteration to, improper installation, or misuse of this product voids the warranty. KAO's liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for any incidental or consequential loss or damage.